



Product Info

RoHS✓

XBee Explorer Serial

sku: WRL-09111

Description: This is a simple to use, RS232 to serial base unit for the XBee line. This unit works with all XBee modules including the Series 1 and Series 2.5, standard and Pro version. Plug the unit into the XBee Explorer, attach a RS232 cable, and you will have direct access to the serial and programming pins on the XBee unit. The board also supports DTR communication so you can reprogram and configure the XBee unit.

XBee modules, RS232 cable, and power supplies sold below.

Documents:

- [Schematic](#)
- [X-CTU Software](#)
- [XBee Introduction and Buying Guide](#)

Pricing



click on the image to enlarge



[ASCII version](#)

► **Comments 7 comments**

▼ **Related Products 9 related**



• In stock TOL-08269 **RoHS✓**
Wall Adapter Power Supply - 5VDC 1A

[Add to Wish List](#)



• In stock TOL-00298 **RoHS✓**
Wall Adapter Power Supply - 9VDC 650mA

[Add to Wish List](#)



• In stock WRL-09132 **RoHS✓**
XBee Explorer Regulated

[Add to Wish List](#)



• In stock WRL-10416 **RoHS✓**
XBee 2mW RPSMA - Series 2 (ZB)

[Add to Wish List](#)



• In stock TOL-08638 **RoHS✓**
Car Adapter USB Power Supply - 5VDC 650mA

[Add to Wish List](#)



- **In stock CAB-00065**
Serial Cable DB9 M/F - 6 Foot

[Add to Wish List](#)



- **In stock BOK-10324**
Building Wireless Sensor Networks

[Add to Wish List](#)



- **In stock WRL-08687 RoHS✓**
XBee Explorer USB

[Add to Wish List](#)



- **Out of stock WRL-09819 RoHS✓**
XBee Explorer Dongle

[Add to Wish List](#)